

Bluechart g3 / g3 vision prehľad kompatibilných a odporúčaných zariadení pre použitie námorných máp Bluechart g3/g3 vision (marec 2019)

POZNÁMKA: Spoločnosť Garmin neustále prináša na trh nové zariadenia, ktoré nemusia byť obsiahnuté v tomto zozname. Pre aktuálny zoznam kompatibilných zariadení s námornými mapami Bluechart g3 / Bluechart g3 Visio, navštívte stránku www.garmin.com alebo www.garmin.sk

VYSVETLIVKY: **C** = kompatibilné **R** = odporúčané **L** = limitovaná kompatibilita (nepodporuje všetky funkcie) **X** = nekompatibilné

Katalógové číslo	Názov zariadenia / série	g3(*) S & R veľkosti	g3(*) L & XL veľkosti	g3 Vision S & R veľkosti	g3 Vision L & XL veľkosti	Legacy g2 HD(*) všetkv	Legacy g2 Vision HD všetkv
Rôzne	EchoMAP 50s / 50dv / 70s / 70dv	C	C	R	R	C	R
Rôzne	EchoMAP 42 / 45 / 52 / 55 / 71 / 72 / 75 / 91 / 92 / 95	C	C	R	R	C	R
Rôzne	EchoMAP CHIRP 42 / 45 / 52 / 55 / 72 / 75 / 92 / 95	C	C	R	R	C	R
Rôzne	EchoMAP Plus 42 / 45 / 62 / 65 / 72 / 75 / 92 / 95	C	C	R	R	C	R
Rôzne	GPSmap 1022 / 1222 (including XSV models)	C	C	R	R	C	R
Rôzne	GPSmap 1222 Touch / 1222 Touch XSV	C	C	R	R	C	R
010-00591-00	GPSMAP 4008	C	L	L	X	C	R
010-00690-00	GPSMAP 4010	C	L	L	X	C	R
010-00592-00	GPSMAP 4012	C	L	L	X	C	R
010-00515-20	GPSMAP 420	C	L	L	X	C	R
010-00516-22	GPSMAP 420s DF xdcr	C	L	L	X	C	R
010-00516-24	GPSMAP 420s w / o xdcr	C	L	L	X	C	R
Rôzne	GPSMAP 421 / 421S	C	L	L	X	C	R
010-00767-02	GPSMAP 451 UK	C	L	L	X	C	R
010-00767-03	GPSMAP 451s UK w / o xdcr	C	L	L	X	C	R
010-00593-00	GPSMAP 5008	C	L	L	X	C	R
010-00594-00	GPSMAP 5012	C	L	L	X	C	R
010-00692-10	GPSMAP 5015	C	L	L	X	C	R
010-00610-00	GPSMAP 520	C	L	L	X	C	R
010-00611-01	GPSMAP 520s DF xdcr	C	L	L	X	C	R
010-00611-00	GPSMAP 520s w / o xdcr	C	L	L	X	C	R
Rôzne	GPSmap 521 / 721	C	C	R	R	C	R
010-00597-00	GPSMAP 525	C	L	L	X	C	R
010-00598-01	GPSMAP 525s DF xdcr	C	L	L	X	C	R
010-00598-00	GPSMAP 525s w / o xdcr	C	L	L	X	C	R
Rôzne	GPSMAP 526 / 526S	C	L	L	X	C	R
010-00763-02	GPSMAP 551 UK	C	L	L	X	C	R
010-00763-03	GPSMAP 551s UK w / o xdcr	C	L	L	X	C	R
010-00775-02	GPSMAP 556 UK	C	L	L	X	C	R
010-00775-03	GPSMAP 556s UK w / o xdcr	C	L	L	X	C	R
Rôzne	GPSmap 527 / 557 / 721 / 751 (including XS models)	C	C	R	R	C	R
010-00750-00	GPSMAP 6008	C	L	L	X	C	R
010-00751-00	GPSMAP 6012	C	L	L	X	C	R
010-00749-00	GPSMAP 7012	C	L	L	X	C	R
010-00748-00	GPSMAP 7015	C	L	L	X	C	R
Rôzne	GPSmap 720 / 720s	C	L	L	X	C	R
Rôzne	GPSmap 722 / 922 (including XS models)	C	C	R	R	C	R
Rôzne	GPSmap 74xx (including XSV models)	C	C	R	R	C	R
010-00835-04	GPSMAP 750 UK	C	L	L	X	C	R
010-00835-05	GPSMAP 750s UK w / o xdcr	C	L	L	X	C	R
Rôzne	GPSmap 80xx / 8520	C	C	R	R	C	R
Rôzne	GPSmap 820 / 1020 (including XS models)	C	C	R	R	C	R
Rôzne	GPSmap 84xx (including XSV models)	C	C	R	R	C	R
Rôzne	GPSmap 87xx (black box)	C	C	R	R	C	R
Rôzne	núvi 5XX series	C	C	X	X	C	X